

# Air Cylinder



300 bars/4350 psi gives 6 shots with the PLT Launching Unit

[Article 1306](#)    [Aircylinder 300 bars](#)    1

Air Cylinder with closing valve. 1,45 liter (50 fl oz). Work pressure 300bars/4350psi

For filling to 300 bars (4350 psi), simply connect the air cylinder to a standard scuba diving (breathing air) compressor with standard 5/8" threads according to DIN 477. We also have air cylinders approved according to North American standards.

Air Cylinder is approved according to Council directive 2010/35/EU, EN 1964-2 ISO 9809-2

Closing Valve is approved according to Council directive 2010/35/EU, EN ISO 10297:2006 and EN 144-1:2005



## Accessories

Air filling hose with couplings and pressure releaser.

Left picture used for connection between air cylinders.

Right picture used for connection to an air compressor.