

PLT® Rescue Buoy Long Range Projectile



Made from ABS plastic and aluminium. The line is stored inside the projectile. Projectile that contains an automatic inflatable life buoy. Will inflate within 2 sec. after entering the water.

Article 2102 **Projectile PLT® Rescue Buoy Long Range** 1

Can only be used with PLT® and Art. No. 1303 Launching Tube Rescue 230. The inflator has an expiry date. Uses 33gram CO2 cartridge. Buoyancy 155 N. The Rescue Projectile must never be launched without the end plug (Art. No. 2104).
Typical launching distance with a dry and clean line of 3,2mm (Art. No. 2103): 220m
Breaking strength of the line: 2000N (204kg).



Re-Usable Life Buoy

Reloading the line inside the projectile with the Art. No. 2200 and Repacking the Life Buoy by using Art. No. 7034.

